

Chocolate Chip Cookie Mix In A Jar



Wet Ingredients Needed:

- 1 cup room temperature butter
- 1 egg
- 1 teaspoon vanilla

Directions

1. Preheat oven to 350F. Start by adding the butter, egg and vanilla into the mixing bowl and mix until smooth.
2. Turn your mixer down to medium speed and slowly add the ingredients from the jar to your mixing bowl with the wet ingredients. Keep mixing until it starts to form cookie batter consistency.
3. Use a cookie scoop to add cookie dough to your prepared cookie sheet (either with parchment paper or sprayed with non-stick spray).
4. Bake for 12 minutes.